



TRENDY ECO

1/4 TURN RIGHT | 1/4 **TOURNANT DROIT** | 1/4-SLAG RECHTSE | 1/4-WENDELUNG RECHTS
1/4 DE GIRO DERECHA | 1/4 VOLTA PARA A DIREITO | 1/4 GIRATA A DESTRA | 1/4 TURNANTĂ DREAPTA





01 30x190x2802 x1 	02 30x190x2802 x1 	03 70x70x1889 x1 	04 70x70x1224 x1 	05 70x70x1228 x1 	06 30x80x1440 x1 	07 30x80x1192 x1 	08 016x1452 x4 	09 016x1204 x4
10 30x323x1040 x1 	11 30x490x820 x1 	12 30x416x736 x1 	13 30x555x1079 x1 	14 30x406x762 x1 	15 70x70x370 x1 	16 70x70x570 x1 	17 18x209x760 x10 	18 18x209x828 x1
19 18x209x828 x1 	20 18x180x735 x1 	21 30x190x762 x10 	22 012x5 x60+4 	23 020x5 x2 	24 040x5 x2 	25 06x30mm x6 	26 04x40 x56+2 	27 05x50 x20+1
28 05x60 x18+1 	29 34x16 x2 	30 M8x68 x2 	31 M8x70 x2 	32 M8 x2 	33 04,2x40mm x8+1 	34 04x35mm x8 	 	




Ph2/3 03 03 13
 Pz2/3 Tx10-30 07 04 08



x2 x4




1





2



4





3






5







2/9







6




7





8



9



10

